

Upgrade Options

AMC100 and Upgrade Options	AMC100	Pro Version	I/O Version
end of travel detection / stop on end of travel		x	
open loop fine positioning		x	
LabVIEW	x	x	x
DLL	x	x	x
platform independent JSON drivers	x	x	x
AquadB input and output (LVTTL)			x
trigger input			x
stepper input			x
input/output differential			x
n steps command		x	
multidevice operation	x	x	x
MOVE gui (flexibility to mix axes from different controllers)		x	
auto reset	x	x	x
target range around set point adjustable	x	x	x
daisy chaining between multiple AMC100		x	